

Hypergolicity and ignition delay study of green bipropellant system without catalyst (PPT)

Quesada Mañas, Jaime; Jyoti, Botchu Vara Siva; Gurumallapa, Pranav

Publication date

2020

Document Version

Final published version

Citation (APA)

Quesada Mañas, J., Jyoti, B. V. S., & Gurumallapa, P. (2020). *Hypergolicity and ignition delay study of green bipropellant system without catalyst (PPT)*. Aerospace Europe Conference 2020, Bordeaux, France.

Important note

To cite this publication, please use the final published version (if applicable).
Please check the document version above.


Copyright

Other than for strictly personal use, it is not permitted to download, forward or distribute the text or part of it, without the consent of the author(s) and/or copyright holder(s), unless the work is under an open content license such as Creative Commons.

Takedown policy

Please contact us and provide details if you believe this document breaches copyrights.
We will remove access to the work immediately and investigate your claim.

Frame rate : 6400
Resolution : 1024x1024





AerospaceEurope Conference 2020

BORDEAUX, FRANCE | 25 - 28 FEBRUARY 2020



Hypergolicity and ignition delay study of green bipropellant system without catalyst

Ir. Jaime Quesada Mañas

Dr. B. V. S. Jyoti

Pranav Gurumallapa

*Space Systems Engineering
Delft University of Technology*


New Trends: Green Propellants



- Non-toxic 
- Easier and safer to handle   
- Reduce cost

Hydrogen Peroxide
Ethanol (*EtOH*)

H₂O₂
C₂H₅OH



Initiation of the process:

Catalysts

Spark

Thermally?




Research Goal

*Hypergolic
Green
H₂O₂
EtOH
Thermally*

Is the use of thermal energy sufficient to achieve in-house refined High Test Peroxide decomposition to allow for dual-mode system, as monopropellant and as pseudo hypergolic bipropellant with ethanol, and if so, under what conditions?





- **Procurement of H₂O₂** through in-house approach
- **Thermal decomposition of HTP** to provide detailed study of required conditions
- **Pseudo hypergolicity** to prove and characterize its possibility avoiding catalysts
- **Characterization** to provide with an understanding of the the process for its future application

Outline



- | | |
|------------------------|-------------------------------------|
| 1. Direct obtaining | 1. Temperature: needed and expected |
| 2. Freezing method | 2. Experimental setup |
| 1. Innovative solution | 1. Methodology |
| | 2. Test results |

Procuring High Test Peroxide

			
ICAO <40%	IMO <60%	ADR >60% 70-98%	

✓ Suppliers

Supplier & Technology
 **esa**
 European Space Agency

✓ Research institutions

• 88% / 87.5 %

• 1kg 





The Freezing Method

Propellant Procurement

Monopropellant:
Thermal decomposition

Bipropellant:
Pseudo-hypergolicity





Innovative Approach: Patent Results

Propellant Procurement

Patent

Monopropellant:
Thermal decomposition

Bipropellant:
Pseudo-hypergolicity



- ✓ Maximum concentration: **99.5%**
- ✓ Minimum initial concentration: **10%**
- ✓ Average of 1.1% increase per hour
- ✓ Fastest recorded: **99.5% in 23h**
- ✓ Order of magnitude **cheaper** than available systems
- ✓ Improvements show **reduction in time** and increase in yield


START-UP SPIN-OFF
INCOMING

Monopropellant: Thermal Decomposition




1. **Temperature: needed and expected**
 2. **Experimental setup**
-
1. **Methodology**
 2. **Test results**



Thermal Decomposition: Theory



- What temperature is expected to happen?
- ✓ Adiabatic flame temperature



The Experimental Setup



Methodology


- Concentrations: 75, 80, 85, 90, 95 %
- Heating plate: 50, 100, 150, 200, 250, 270 °C
- Droplet: 0.13 mL (H₂O₂)
- HSPC: 6,400 fps
- Thermocouples: (1-3) 55Hz



T [°C±10 °C]	Concentration [%±1%]				
	75	80	85	90	95
50	1	7	13	19	25
100	2	8	14	20	26
150	3	9	15	21	27
200	4	10	16	22	28
250	5	11	17	23	29
270	6	12	18	24	30




Results: Valid Combinations and Profile




80% HTP on 270°C

Results: Maximum Temperature



Results: Decomposition Time Delay




Decomposition Lessons




- Minimum of 200 °C and 80% HTP is needed to decompose
- All combinations from 80% HTP and 200 °C can auto ignite ethanol
 - T_{max} increases with concentration
- DDT decreases with temperature
 - Heating element at 270 °C gives less than 100 ms
- **Thermal approach is possible for monopropellant**

Pseudo-hypergolic demonstration



FASTCAM Mini
Frame rate :
Resolution :

Frame rate : 6400 Frame rate : 6400 Frame rate : 6400 Frame rate : 6400 Frame rate : 6400 Frame rate : 6400
Resolution : 1024x1024 Resolution : 1024x1024 Resolution : 1024x1024 Resolution : 1024x1024 Resolution : 1024x1024 Resolution : 1024x1024



95% HTP / EtOH on 250°C

95% HTP / EtOH on 270°C

Start-Up Spin-Off
incoming

Conclusions and recommendations

- Study on the **purity of the HTP** in terms of stabilizers
- Larger funding for setup with close chamber: **pressure variations**
 - Color-mode equipment
 - Impinging mechanism
- Test the approach on a **flow of hydrogen peroxide**
- Detail study on the exact **liquid-to-vapor ratio** prior to decomposition for better modeling of the approach
- Vary the **height** of the setup to mimic different injector situations

FASTCAM Mini AX200 type 900K-M-32GB
Frame rate : 6400
Resolution : 1024x1024

Thank you for your attention!

Questions?

